



MODEL DHE-DL500A

DRUM LIFTER 500A

Instruction Manual





DHE Materials Handling Equipment

Drum Lifter 500A

Instruction Manual

DHE Materials Handling Equipment
28 Aster Avenue
Carrum Downs VIC 3810
Phone: 1300 067 281
Fax: (03) 9775 1662
Website: www.dhemhe.com.au



Table of Contents

1.0: FIGURE AND DIMENSION	3
1.1 : TECHNICAL SPECIFICATION	3
2.0: OPERATING PROCEDURE	4
2.1 : LIFT DRUM.....	4
2.2 : TRANSPORT DRUM	4
2.3 : PUT DOWN DRUM	4
3.0: WARNING	5

The Drum Lifter 500A is an all steel construction drum lifter that works easily with overhead crane or jib attachment.

- Handles open or closed steel drums.
- It keeps drums upright during lift, reducing spills and injuries.
- Quick and gentle loading.

1.1: Technical Specification

Model	DHE-DL500A
Lifting Capacity	500kgs
Drum Size	200 Litre
Unit Weight	5kgs

2.0 : Operating Procedure

2.1 : Lift Drum

Place the Drum Lifter 500A on the hook of the overhead crane or jib attachment vertically.
Lock the hook in position.

2.2 : Transport Drum

Raise the crane or jib attachment as required until the drum is lifted off the ground of platform. Manoeuvre the drum to the required area.
Notice: To minimise hazard risk it is strongly recommended to move the drum whilst the drum's position is as low as possible.

2.3: Put Down Drum

After moving the drum to the destination, slowly lower the crane or jib attachment until the drum is securely in the required area.

3.0 : Warning

- Never overload the Drum Lifter 500A beyond its rated capacity.
- Place the drum on the low position when there is no requirement to lift.
- Raise the drum slightly on the ground when transit drum, do not need to lift it high